

Panda Stand™

Eco-Friendly Retractable Bamboo Banner Stand

Graphic Installation Instruction



1. Place the top rail on a flat surface with the adhesive tape facing up.



2. Remove the release liner exposing the adhesive tape on the top rail.



3. Attach the graphic with the printed side facing up and press it down firmly, ensuring the graphic is securely fastened.



4. While attaching the graphic, keep the graphic edge 2mm/0.1" away from the top rail edge.



5. Position the Panda with the backside facing you.



6. Remove the release liner of the adhesive tape on the lead sheet. Attach the bottom of your graphic panel onto the exposed adhesive.



7. Hold onto the graphic panel firmly while removing the tension key from the side of the base. Graphic instantly gains tension when the key is pulled out.



8. Allow the graphic to slowly retract into the base of the unit. Graphic installation is now completed.

How to change the graphic



1. Kneel on the base to increase extra weight and stability on the base. Grab the graphic edge and pull out the graphic. While the bleed is shown, insert the tension key into the hole on the end plate (smaller hole). Graphic tension is instantly secured when the key fits in the hole completely.



2. Take down the graphic from the unit. Peel off the graphic from the top rail and bottom bleed. You can follow the instruction of graphic installation and mount the new graphic onto the hardware now.

The information in this brochure is subject to change without notice. For prices and further info, please call 800-280-6013

Drytac USA Toll Free: 800-280-6013 Drytac Canada Toll Free: 800-353-2883

www.drytac.com

DRYTAC®